

MORGAN BED ASSEMBLY INSTRUCTIONS

1. Position bedhead against wall where required. Lie out side rails and foot rail roughly in position on floor.
2. You have 8 large black screws that are to be fitted to brackets on bedhead and foot rail. Fit two screws to threaded holes of each bracket using allen key provided. Fit screws loosely. This will allow brackets of side rail to clip over screws.
3. Attach one side rail to foot end. Clip on and push to bottom. Loosen screws if too tight. Repeat for other side. Do not tighten screws until all brackets are engaged.
4. Now attach one side rail to bedhead. Again push down to bottom before tightening screws. All screws can now be tightened until rails meet flush with head and foot. Do not overtighten
5. Once bed frame assembled fit slats provided. The slats fit between each block on side rails.

